

Lecture 07 - HIGH-SPEED

Advanced Layout: High-Speed

Outline

- Introduction
- High-Frequency routing
- PCBs for Planar Microwave Devices
- Examples


High-Frequency Signals

Definition

Signals are merely useful, semi-periodic waveforms that we represent as changing voltage potentials or currents.

Examples include:

- Analog sensor outputs
- Digital communications
- Radio signals
- Output of an on/off switch




<https://www.monolithicpower.com/en/analog-vs-digital-signal>

High-Frequency Signals

Definition

For simplicity, we can represent all signals as simple sinusoidal waves of current that produce electric and magnetic fields on our PCB

(Fourier decomposition allows us to do this)



High-Frequency Routing


Microstrip

Using Ansys HFSS to analyze how high-frequency signals are affected by PCB design elements

Taking a look at a microstrip model, consists of:



- Copper trace
- Dielectric (FR408HR used)
- Copper ground plane

Lumped element ports are attached to either end of the trace



High-Frequency Routing

Microstrip



<https://www.signalintegrityjournal.com/articles/2378-measuring-the-bulk-dielectric-constant-dk-on-a-microstrip-with-a-ldr>

High-Frequency Routing


Microstrip

We can inject high-frequency signals on either end/port on the trace and measure how they are affected:

- Signal degradation
- Coupling
- Radiation
- Reflections

Able to visualize electric fields throughout materials (analogous to the current flow)


Electric fields radiate around trace




High-Frequency Routing

Microstrip

Electric field plotted on trace (2.4GHz source)




Signal Loss (dB) vs. Frequency



High-Frequency Routing

Impedance Matching



For a microstrip, impedance can be adjusted by changing the trace width.

The ports are 50Ω terminated. Matching the trace impedance close to 50Ω will result in lower loss.


High-Frequency Routing

Impedance Matching

The currently modelled trace has a very high impedance ($>50\Omega$). Therefore, widening it provides a better impedance match.

Impedance characteristics for a microstrip are affected by:


- Trace width
- Trace thickness
- Dielectric height
- Dielectric Constant (D_k , E_r)



High-Frequency Routing

Coupling

What happens if we put another trace in parallel?




High-Frequency Routing

Coupling

Notice how the electric fields propagating through the air around the excited (left) trace reaches the parallel (right) trace and induces internal fields



A smaller, measurable copy of the signal is being coupled to the other trace

This can become a big issue for sensitive systems



High-Frequency Routing

Coupling



High-Frequency Routing


Mitigating Coupling

Coupling can adversely affect our signals.

At best, the coupled signals increase noise in our signal. At worse, they appear as valid signals at a receiving device (crosstalk)

We can reduce coupling by avoiding parallel signal traces (i.e., have them cross perpendicularly on different layers)

Increasing the separation between traces can also help




High-Frequency Routing

Mitigating Coupling

Increasing the distance between parallel traces will weaken coupling fields (inversely proportional to distance)

For differential traces, this coupling is utilized to maintain a particular differential impedance


- Ensure to follow impedance requirements for differential signal trace pairs




High-Frequency Routing

Mitigating Coupling

Add a ground trace/pour/via-fence between





Radiated fields couple to the return path (GND)



High-Frequency Routing

Mitigating Coupling



Adding ground pours/planes are easy methods for improving signal integrity


High-Frequency Routing

Microstrip Bends

Impedance mismatches can occur at abrupt discontinuities in a trace, such as sharp (90 degree) bends



The bend itself can resonate and have its own (different) impedance from the rest of the microstrip

The result is signal reflections, radiation, and degradations!



High-Frequency Routing


Microstrip bends



High-Frequency Routing


Microstrip Bends

Solution: smooth, wide bends




High-Frequency Routing

Microstrip Bends



Even field distribution throughout bend



Smooth, weaker near-field radiation patterns

High-Frequency Routing


Key Takeaways

- ❑ As signals reach greater frequencies, their wavelengths decrease, which results causes greater susceptibility to wave phenomenon and parasitic circuit elements
- ❑ Impedance mismatches between traces, discontinuities, and devices can lead to signal degradation, reflection, and radiation, which we can simulate
- ❑ Use appropriate high-frequency PCB structures (e.g., microstrip, coplanar waveguide) when impedance matching is needed
- ❑ Close, parallel traces can couple to one another, use appropriate spacing, ground pours, and via fences to reduce coupling
- ❑ Sharp trace turns can cause impedance mismatches, use smooth bends instead

Examples

Examples



24 GHz Radar



Phased Array!

THE ART AND SCIENCE OF PCB DESIGN



IAP 2025



<https://www.analog.com/en/design-center/evaluation-hardware-and-software/evaluation-boards-kits/eval-tinyrad.html#feb-overview>

Examples

28 GHz Amplifier




<https://www.analog.com/en/design-center/evaluation-hardware-and-software/evaluation-boards-kits/EVAL-HMC994APM5.html#eb-overview>

Planar Microwave Devices

Planar Microwave Devices

RF Passive Components



We can use PCBs to create passive microwave components


PCBs offer a cheaper medium for microwave device fabrication

Also allows for greater integration of an RF system onto a single board


Microstrip Resonators

Open-Circuit Stub

A resonator can be created using a length of microstrip and a termination



(a)



(b)


In this case, an open-circuit stub can be added

- Acts like a shunt capacitor when its length is small


Microstrip resonators

Filters

Different stub lengths and terminations can create different LC combinations







We can utilize this effect to create filters



<https://electronics.stackexchange.com/questions/460101/deriving-microstrip-stub-equations>





Microstrip Devices

L-Band Stub Low Pass Filter







Microstrip Devices

S-Band Coupled Line Band Pass Filter



Microstrip Devices

S-Band Directional Coupler




Same principle as the coupling microstrips!



Microstrip Devices

Patch Antennas

Recall how the microstrip has fringing fields?



We can use the fringing fields to radiate power → Microstrip Antenna!




<https://www.signalintegrityjournal.com/articles/2378-measuring-the-bulk-dielectric-constant-dk-on-a-microstrip-with-a-tdr>


Microstrip Devices

Patch Antennas

Creating a resonating wave in the microstrip patch results in changing fringing fields





Fringing fields form a far-field radiation pattern



Microstrip Devices


Patch Antenna Arrays




https://www.researchgate.net/figure/Series-fed-patch-antenna-array-for-60-GHz-Both-developed-antenna-arrays-have-minimum_fig4_267718251

https://www.qwed.eu/QuickWave/help/qw-modeller_examples_guide/15_rectangular_patch_antenna_8x8_array.htm

Integrated Microwave Assemblies



<https://www.viasion.com/radar-pcb/>



https://www.researchgate.net/figure/mage-of-the-radar-system-The-PCB-on-top-is-the-RF-frontend-which-holds-the-RF_fig2_313686839